



Funktionen:

Dieser Schrittzähler zeigt Ihnen die Anzahl der zurückgelegten Schritte (bis 99.999 Schritte) an.

Tragehinweise:

Befestigen Sie den Schrittzähler gem. der Abbildung mit dem Clip am Hosenbund oder Gürtel.

**Bedienung:**

Vor der ersten Inbetriebnahme, entfernen Sie bitte den Schutzstreifen am Batteriefach.

Befestigen Sie diesen Schrittzähler am Hosenbund und betätigen Sie die Taste Reset. Ab diesem Zeitpunkt zeigt Ihnen der Schrittzähler die Anzahl der zurückgelegten Schritte an.

Drücken Sie die Taste „Reset“ um den angezeigten Wert auf 0 zu stellen.



RESET

**Batteriewechsel:**

Wenn die Anzeige schwach oder unvollständig wird, ersetzen Sie bitte die Batterie (1 Stück 357A oder Vergleichstyp). Hierzu öffnen Sie das Batteriefach, entnehmen die alte Batterie (bitte sachgerecht entsorgen, nicht in den Hausmüll werfen). Die neue Batterie legen Sie mit dem + Pol nach oben in das Gerät ein und schieben das Fach wieder zu.

Fehlerbehebung:



Sollte der Schrittzähler nicht ordnungsgemäß funktionieren, entfernen Sie bitte die Batterie und legen diese erneut ein. Ggf. wechseln Sie die Batterie gegen eine neue aus.

Functions:

This step counter records the number of steps taken (up to 99.999 steps).

How to wear:

Clip the step counter to your waistline or belt as shown in the picture below.

**How to use:**

Please remove the strap of the battery cover on the back in order to activate the instrument.

Clip the step counter to your waistline and press the reset button to clear. Now your step counter records the number of steps you walk or jog.

Press „Reset“, if you want to clear the result and return to zero.

**Change of batteries:**

If the display begins to fade or only partial numbers are shown, please replace the battery (1 piece 357A or similar). Open the battery cover and remove the old battery (please dispose environmental friendly). Place a new battery with the + sign upward inside the compartment and close the cover again.

Problems:

If the step counter does not work accordingly, please remove battery once and put it back in. If necessary, please replace battery.

