



Funktionen:

- Dieser Schrittzähler zeigt Ihnen die Anzahl der zurückgelegten Schritte (bis 99.999 Schritte) an.
- Abschaltautomatik

Tragehinweise:

Befestigen Sie den Schrittzähler gem. der Abbildung mit dem Clip am Hosenbund oder Gürtel.

**Bedienung:**

Befestigen Sie diesen Schrittzähler am Hosenbund und betätigen Sie die Taste Reset. Ab diesem Zeitpunkt zeigt Ihnen der Schrittzähler die Anzahl der zurückgelegten Schritte an.

Drücken Sie die Taste „Reset“ um den angezeigten Wert auf 0 zu stellen.



RESET

Batteriewechsel:

Wenn die Anzeige schwach oder unvollständig wird, ersetzen Sie bitte die Batterie (1 Stück AG13 oder Vergleichstyp). Dazu öffnen Sie die beiden Schrauben auf der Rückseite (siehe Bild), heben die Gehäusehälfte ab und entnehmen die alte Batterie (bitte sachgerecht entsorgen, nicht in den Hausmüll werfen). Die neue Batterie legen Sie mit dem + Pol nach oben in das Gerät ein drücken den Gehäusedeckel wieder auf und verschrauben diesen wieder.

Fehlerbehebung

Sollte die Anzeige schwach / fehlerhaft sein, wechseln Sie die Batterie. Sollten die angezeigten Schritte nicht stimmen, prüfen Sie, ob der Schrittzähler richtig (Position) am Hosenbund befestigt ist.

Spezifikationen:

- | | |
|------------------------|----------------|
| • Batterie: | AG13 |
| • Batterielebensdauer: | ~ 12 Monate |
| • Abmessungen: | 47 x 36 x 22mm |
| • Gewicht: | ca. 16 g |





Functions:

- This step counter records the number of steps taken (up to 99.999 steps).
- Automatic shut-off

How to wear:

Clip the step counter to your waistline or belt as shown in the picture below.

**How to use:**

Clip the step counter to your waistline and press the reset button to clear. Now your step counter records the number of steps you walk or jog.

Press „Reset“, if you want to clear the result and return to zero.

**RESET****Battery replacement**

When the display becomes dim or is fading, replace the battery with a new AG13, or equivalent. Open the battery cover and remove the screws with a screwdriver. Take off the housing and remove the old battery (protect the environment by taking empty batteries to authorized disposal stations) Insert the new one into the battery holder (with + side up) and close the battery cover with the screws.

Trouble shooting

If the displayed steps are incorrect, check the upright position of the pedometer on your belt or waistline.

Specifications:

- | | |
|-----------------|----------------|
| • Power source: | AG13 |
| • Battery life | ~ 12 months |
| • Product size: | 47 x 36 x 22mm |
| • Weight: | approx. 16 g |

